

CAUTION

DRUM/SPINDLE SANDER

WEAR APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT

(eye, face, hearing, etc.)

- Never start the machine unless all the guards are in place and properly adjusted.
- Do not mix incompatible dusts (steel and aluminum).
- Beware of moving machinery parts.
- Keep the work area clean. Foreign materials may cause poor footing.
- Make sure the dust collection system, if provided, is connected and operational.
- Use proper abrasive disk and/or belt for material being processed.
- Beware of contact with the unguarded portion of the drum/spindle above and below the worktable.
- Replace disks if abrasive surface has rips, tears, or worn areas.
- Filler plate opening should not exceed 1/8 inch.
- De-energize and lockout all energy systems before making adjustments/repairs.
- Do not wear gloves, jewelry, or loose clothing.
- Ensure that operator is properly trained and has read the owner's operation manual.

Note: Immediately report all machinery malfunctions to management.